

## Exhibit Rail Installation Instructions

1

Exhibit rails have a very aggressive pressure-sensitive adhesive backing with a peel-back release liner. Peel the release liner from the back of the exhibit rail and adhere the exhibit rail to preferred location on the wall.

2

After exhibit rail is attached to the wall, slide the cork out of the metal frame.

3

Drill a hole in the center of the metal exhibit rail frame.

4

Use the 1 ½" flat head screw with the shoulder washer and screw it through the exhibit rail into the wall.

5

Slide the cork back into the metal exhibit rail frame.

6

Slide the end caps onto the ends of the exhibit rail.

7

Use the pre-drilled holes on the end caps as guides and drill a 3/16" hole on both ends of the exhibit rail.

8

Screw the 1 ½" pan head screw through the holes drilled at the ends of the exhibit rail. Screws should go through the end caps and exhibit rail, securing the exhibit rail to the wall.